

1. Product Overview

The Nokia customer premises equipment (CPE) F-010G-F is a small form factor CPE that defines a new era in broadband access technology by addressing the unique in-home needs of second-generation G.fast. The Nokia CPE F-010G-F is a compact and easy to manage CPE with one electrical Gigabit Ethernet (GigE) connection (RJ-45) for high-speed connectivity within the home, one G.fast twisted pair connection (RJ-11) and one G.fast coax connection (F-connector).



The Nokia CPE F-010G-F has an integrated PSE (Power Source Equipment) that enables reverse power feeding of the G.fast DPU (Distribution Point Unit).

A. Technical Specifications

- Height: 158 mm (6.2 in)
- Width: 200 mm (7.9 in)
- Depth: 37 mm (1.5 in)
- Weight: 420 g (0.92 lb), excluding power adapter

Power consumption:

- Local powering with 58V DC input
- Power consumption without reverse powering: 10 W
- Power consumption with reverse powering: 25W

B. Manufacturer Information

For Products Purchased in the United States

The products are imported by Nokia of America Corporation.

- Offices: <https://www.nokia.com/contact-us/offices/#north-america>
- Support: <https://www.nokia.com/networks/business-support/>
- Other contacts: <https://www.nokia.com/contact-us/>

Please contact your Internet Services Provider in case of questions on the product.

2. Safety Guidelines

ALWAYS READ THE PRODUCT GUIDE BEFORE SET UP OR USE OF THE PRODUCT. IT IS YOUR RESPONSIBILITY TO FAMILIARIZE YOURSELF WITH THE PRODUCT GUIDE AND WARNINGS, AND TO USE A PRODUCT PROPERLY. CONTACT YOUR INTERNET SERVICES PROVIDER FOR FURTHER QUESTIONS.

Warning - Risk of electric shock or fire

Connect the Product power adaptor or cord to the right supply voltage (for example, 120V AC in US).

The socket-outlet shall be easily accessible.

Pay attention to the power load of the electrical outlet and possible extension cord. An overburdened power outlet or damaged cords and plugs may cause electric shock or fire. Check the power cords regularly. If you find any damage, replace the cord immediately.

Do not connect the plug into an extension cord, receptacle, or other outlet unless the plug can be fully inserted with no part of the blades exposed.

Leave adequate space for heat dissipation to avoid any damage caused by overheating the Product. Do not cover the Product or its ventilation holes. Blocking the ventilation holes may cause fire.

Use the power adapter provided with your Product and do not fasten the power cable to building surfaces. Ensure the cable can move freely. Do not place heavy objects on the cable.

Do not use the Product outdoors, and make sure all the connections are indoors.

Do not install, use, or service this Product during a thunderstorm. There is a remote risk of electric shock from lightning.

Caution - Potential equipment damage

Follow these recommendations to protect yourself and the Product from harm:

- Do not insert any sharp object into the openings of a Product.
- Do not put the Product near a heat source. Avoid placing the Product in direct sunlight.
- Do not put the Product in damp or wet locations; for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool. Do not spill any liquid on the Product.
- Do not touch the Product or its power adapter or cord with wet hands.
- Do not place the Product on an unstable surface or support.
- Do not place heavy objects on top of the Products.
- Do not use liquid or aerosol cleaners; unplug the Product and use a soft, dry cloth for cleaning.
- When connecting a PC or other electronic device to a Product, make sure you use the right cables and connect the device to the right port of the Product. Incorrect connections may damage the device and/or the Product.
- Do not open or try to open the Product. Opening or removing covers can expose you to dangerous high voltage points or other risks.

Keep your product and accessories out of reach of pets. They could damage it and cause injury or electrocuting.

If the Product malfunctions or fails to perform as expected, stop using it immediately.

The product is expected to operate at a temperature of -5 to 45 degrees Celsius for a relative humidity between 5% and 90%.

3. Install the CPE

1. Connect the power cable to the case on the PWR power port.
2. Connect the connector (coaxial or RJ-11 telephone connector) to the corresponding port of the case.
3. Connect the case to the home router via the Ethernet cable.
4. Connect the power socket to the wall socket.

modifications will invalidate all applicable regulatory certifications and approvals.

The Product and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

© 2021 Nokia Solutions and Networks Oy

Nokia is a registered trademark of Nokia Corporation

4. FCC Declaration of Conformity



This device complies with part 15 of the U.S. FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications:

Do not make any changes or modifications to the Product without the prior express written approval of Nokia. Any changes or modifications made without express written approval could void the user's authority to operate the device.

FCC Guidelines for Human Exposure

The Product complies with FCC radiation exposure limits set forth for an uncontrolled environment. The Product should be installed and operated with minimum distance of 32cm between the radiator and your body.

FCC Information to User

The Product does not contain any user serviceable components and is to be used with approved antennas only. Any product changes or